Celebrity Actions

All our recliners are available in up to 5 action options in every chair size. They are tested to support weight up to 160kg/25stone (Cloud Zero 30 stone).

Manual Recliner




- Manual recliners are available with either a latch or handle option. A latch is fitted as standard. Handles are available upon request at no additional charge.
- Release the latch for the footrest to rise then push gently on the arms and move your back into the chair to recline the chair back.
- To return the chair to the seated position sit upright and push the footrest down until it clicks into position.
- We recommend that users with limited lower leg strength select from our powered recliner range.
- 'Wall-hugger'' action operates 5 inches from the wall.

Single Motor Powered Recliner

Single Motor Powered Recliners are operated using a "keypad" located on the side of the chair. Each keypad includes a standard 1 Amp USB socket. The electric control system is, operated with a simple "touch of a button."

The recline action can be paused at any point during the cycle, giving flexibility of use. Keypads can be positioned on either the Left Hand Facing (LHF) side, which is standard, or the Right Hand Facing (RHF) side, available upon request at no extra cost.





- The footrest raises to its top level, the chair back will then start to recline.
- " "Wall-hugger" action operates 5 inches from the wall.


Riser Recliners

Each handset includes a standard 1 Amp USB socket. The electric control system is, operated with a simple "touch of a button." The recline action can be paused at any point during the cycle, giving flexibility of use.

Handsets can be positioned on either the Left Hand Facing (LHF) side, which is standard, or the Right Hand Facing (RHF) side, available upon request at no extra cost.

Single Motor Riser Recliner






The footrest will raise to its top level, then the chair back will then start to recline. The rising action will lift the chair to enable the user to exit or access the chair with ease.

Dual Motor Riser Recliner





The footrest and the chair back operate independently to create your perfect sitting position. The rising action will lift the chair to enable the user to exit or access the chair with ease.